


# MANUAL

## for bunkering at UTG bunker station Kiel 1

### Pre arrival information for UTG



- Position on board of used bunker connection(s) (port/starboard, distance fore/aft)
- Bunker connection(s) size hole-hole (sketch) & amount of holes
- If two products to be supplied – is it possible to bunker both at the same time?
- Required bunkering pressure and flow rate
- Free space in bunker tanks (cbm)

### Pre arrival information ship

- *just without agent* - Notice: 1 hour before arrival UTG by phone call (+49 431 301190 - 24h)
- Berth: Connection in line to flash light ashore

### Upon arrival

- Chief engineer (with a stamp) needs to come ashore to UTG staff to fill the checklist promptly after berthing
- During paper works ship's crew shall connect the bunker hose

### Bunkering finished

- Chief engineer (with a stamp) needs to come to UTG staff for final paperwork
- Departure as soon as possible – any delay -> promptly inform UTG

Contact UTG:

E-Mail: [tl-kiel@utg-tanklogistik.de](mailto:tl-kiel@utg-tanklogistik.de) (office hours)

Phone: +49 431 301190 (24h)